

Book Descriptions:

Directv Dvr R15 Manual

Your DIRECTV Plus Receiver has been designed and manufactured to stringent quality and safety. Important Safety Instructions. Meaning of symbols printed on the rear panel of the product. The “bolt of lightning” indicates uninsulated material within your unit may cause an electrical shock. For the safety of everyone in your household, please do not remove product covering. The “exclamation point” calls attention to features for which you should read the enclosed. Install in accordance with the manufacturer’s instructions. A polarized plug has a grounding type plug has two blades and a third. If the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete. Servicing is required when the apparatus. The DIRECTV Plus Receiver should not be used near water for example, kitchen sink, bathtub, pool, damp. Also, do not stack the receiver on top of a “hot component” such as an audio power amplifier. Use of a surge protector is also recommended. Also, place. Note to Satellite Dish Installer. This reminder is provided to call your attention to articles 810 and 820 of the 2002 National Electrical Code. Refer to IMPORTANT. Be sure not to place. Never insert objects of any kind into any openings in the DIRECTV Plus Receiver other than. Place it on a flat, hard surface — do not operate the DIRECTV Plus Receiver on a carpet or. Always unplug your DIRECTV Plus Receiver before moving it. Always unplug the DIRECTV Plus Receiver, TV and other equipment before you connect or. Leave the main power connector accessible the mains connector at the back of the unit in case of CAUTION Electric Shock — never attempt to disassemble the DIRECTV Plus Receiver. Attempted self-repair may also void your warranty. Changes or modifications not expressly approved by the party responsible for compliance by the. Do not drop your DIRECTV Plus Receiver and always move it with care. <http://alumcity.ru/userfiles/call-of-duty-4-ps3-manual.xml>

- **directv dvr r15 manual, directv dvr r15 manual pdf, directv dvr r15 manual download, directv dvr r15 manual instructions, directv dvr r15 manual free.**

Have your DIRECTV Plus Receiver professionally serviced do not attempt to service it. Any changes or modifications in construction of this device which are not expressly approved by. For your information. The identification sticker can be located underneath or on the back of your receiver. The telecommunication network voltage used is the category number 3. Important. Important. This device incorporates an anticopy process technology that is protected by U.S. patents and other. The anticopy process is licensed for noncommercial, home use only. Reverse engineering. Unauthorized changes or modifications. Welcome. 2. Making the Right Connections. 3. Hardware Reference. 4. Getting Familiar. 6. Choose Your Setup. 9. Programming Your Remote Control. 18. Watching TV. 20. The Guide. 24. The Mini Guide. 25. Recording Programs. 26. Pay Per View. 28. The Playlist. 29. Using the MENU. 32. Settings. 32. Audio Options. 33. Category Sort. 35. Pay Per View. 35. Find By. 36. Favorites. 37. Parental Controls. 39. Quick Menu Features for Recording. 42. Troubleshooting. 44. Limited 90 Day Warranty. 52. Product Info. 54. Index. 58. Welcome. Making the Right Connections. Hardware Reference. Getting Familiar. Choose Your Setup. With its astounding variety of channels and choices, crisp digital quality picture and sound and There’s exclusive sports subscriptions for every taste and team. Even access to System has been designed to be simple and user friendly. You’ll find that most features are self-explanatory, with onscreen directions to lead you through them. So, welcome to the family. About Your DIRECTV Plus Receiver. You can select a specific program and set it to record once. You can even record two shows at once. Important. DIRECTV System dish, and a land-based phone connection. Welcome. Whether you’re having your system professionally installed or handling it yourself, be sure to read. Before you begin. Your satellite dish antenna must be installed before you

can begin following the procedures in this. User

Guide. <http://astmasme.com/userData/board/call-of-duty-4-modern-warfare-instruction-manual-ps3.xml>

Professional installation is highly recommended. Your dish needs to be mounted in If you choose to install the dish yourself, see the Package Contents. The following items are included with your DIRECTV Plus Receiver. Chapter 1 General. Satellite Dish Antenna. This is your "dish" and related hardware, af. Your DIRECTV Plus Receiver picks up the signal from your satellite dish antenna and translates it Access Card. It must be properly inserted for your receiver to SVideo jacks and cables provide the best picture quality. You will still need to connect the left and SVideo Jack If your TV has only one input for Video. Best Audio Digital Audio Optical Jack and Cable. The Digital Audio Optical cable provides the best quality audio. The jack and cable use light Digital. Audio. RF Jack and Coaxial Cable Ftype. RF jacks and coaxial cables provide good picture and mono sound quality. They should be used. RF jacks are used to connect to your TV and The RF jacks on the receiver are labeled. SATELLITE IN, OFFAIR IN and OUT TO TV. Note Be sure to use RG6 coaxial cable when RF Jack. Telephone Jack and Cord. The telephone line cord is required to connect your DIRECTV Plus Receiver to a landbased The phone line You will need an RJ11 type modulator jack the Note Do not connect your receiver to a digital PBX phone Phone. Jack. Note Not all cables come with Chapter 1 DIRECTV Plus Receiver Front Panel Getting Familiar. Locate the access card that came packed with your DIRECTV Plus Receiver materials and insert DIRECTV Plus Receiver Rear Panel. Your equipment may not look exactly like the model illustrated. Receiver's OUT TO TV. To watch from your Note that you will not be able to Connect the You must also Chapter 1 We require a landbased telephone connection to communicate periodically with your DIRECTV Plus Receiver. Getting Familiar. Choose Your Setup. There are several ways to connect your receiver to match your particular equipment setup and to The basic steps are as follows.

The following pages give detailed instructions on the types of connections you can make, Connecting Your DIRECTV Plus Receiver to the Satellite Dish. Connect the RG6 RF coaxial cables from your satellite dish to the jacks labeled SATELLITE. IN on the DIRECTV Plus Receiver. Note that in order to take full advantage of your DIRECTV. Plus Receiver's features, you should connect a coaxial cable to each of the two SATELLITE IN Connecting Your DIRECTV Plus Receiver to your TV or VCR. Depending on the connections on the back of your TV or VCR, you have the following options. These connections are described on the following pages. Chapter 1 Using the SVideo cable, connect one end to the SVIDEO output jack on the DIRECTV Plus. Receiver and the other end to the SVideo input jack on the TV. If your TV has a Digital Optical input, connect it to your DIRECT Plus Receiver using a digital Connect the. Do not plug the video yellow into either the DIRECTV Plus Receiver or the TV. Now, continue on page 14, "Connecting Your DIRECTV Plus Receiver to Your Telephone Line." Chapter 1 AUDIO L white and R red and VIDEO yellow output jacks on the back of the DIRECTV Plus This will allow you Now, continue on page 14, "Connecting Your DIRECTV Plus Receiver to Your Telephone Line." Note. If your TV only has one audio input jack use AUDIO L white jack on the back of the DIRECTV Plus Receiver to make Chapter 1 RF Coaxial Connection Good Quality. Using an RF coaxial cable, connect one end to the OUT TO TV jack on the DIRECTV Plus. Receiver and the other end to the antenna in jack on the TV. Channel 4. If you have a local Channel 4, then set the switch to Channel 3. To watch DIRECTV Connecting Your DIRECTV Plus Receiver to Your Telephone Line Plug one end of the telephone cord into a phone jack on your wall or into a phone splitter that DIRECTV Plus Receiver. Completing the Connections. Plug all power cords into electrical sockets. Now, turn to page 16 to learn about Guided Setup and Activation. Note.

<https://www.informaquiz.it/petrgenesis1604790/status/flotaganis21052022-1326>

L and R and VIDEO 1 jacks on the back of the DIRECTV Plus Receiver. Chapter 1 Settings then select Setup. The DIRECTV Plus Receiver will turn on. Using the arrow keys on the remote control, Simply

follow the onscreen directions to complete your setup functions. If you've installed your If, like most people, you had After these setup procedures are complete, you'll see the Satellite Data Acquisition screen, as the Next, you'll be given the opportunity to set up your phone connection, as well as program your. Just follow the screen Important Burnin may cause permanent Activate Your DIRECTV Service. Once all the setup processes are complete, all that's left to do is activate your DIRECTV service. Before you make the call, be sure to. Settings and press SELECT. Then go to Setup and press SELECT. When you're ready, just call 1800DIRECTV 18003473288 and pick the programming Chapter 1 You can program the DIRECTV Remote Control to operate your TV power, volume and Receiver. Once your remote is programmed to work with your TV, the VOL and MUTE key control If you would like to change the VOL and. MUTE to work with another component, you can. Simply set up your remote to work with VOL and MUTE keys to. Point the remote away from your DIRECTV Plus Receiver and Factory Defaults. To reset all the functions of the remote control to the factory defaults, follow these steps AV2 and TV modes. Watching TV Now that everything's set up, you're ready to grab your remote and start surng! With the MODE SWITCH to the left under the DIRECTV logo, press TV POWER. ON. To access the channel of your choice, simply key in its numbers on your remote the Use the black keys on the left side of your remote control to adjust volume up or down The black keys on the right side can take you to the TV recommendations, and special DIRECTV promotions. Press the ACTIVE key to access these features.

<http://artcustomdrums.com/images/Digidesign-Usd-Sync-Manual.pdf>

DIRECTV Plus Features in Live TV This "live buffer" lets you pause, rewind, fast forward or Cruise Controls Use the PAUSE, FFWD, REWIND, REPLAY, RECORD and ADVANCE Pressing FFWD or REWIND multiple times lets you Pressing and holding PLAY If you press FFWD while a program is paused, the If you press PAUSE during a program, the saved portion you can access extends from 90 You can record a program that is If you are viewing a screen with a TV Window, such as the Guide or an Info screen, Chapter 2 Recorded programs can be found in the Playlist. To view the Playlist, press LIST. To return to Cruise Controls The PAUSE, FFWD, REWIND, REPLAY, RECORD and ADVANCE Pressing STOP while you're When you've reached the end of a recorded program, the recorder will ask if you want to For recorded programs, the control bar shows the program duration instead of the start and End Time Start Time. Bookmark. Control Bar Program. Title. Current. Time. Marker. Action. Icon. Record. Bookmarks "Bookmarks" are a way of keeping track of places in a program you'd like to GREEN key. They can be deleted by pressing PAUSE, then the DASH key. You can jump to. Bookmarks by pressing and holding the FFWD key to move forward, or the REWIND key to The Channel Banner. Any time you tune to a channel, you'll see the channel banner appear across the top of the If displayed brightly, alternate audio options If displayed brightly, there are new DIRECTV. Three states Locked INFO on your remote press a second time Music Channels. Your DIRECTV service includes dozens of enjoyable, continuous, commercial free music channels with something for You'll see a special Channel Banner that initially displays the As each song is played, its info will appear in the Chapter 2 The Guide displays listings of current and upcoming programs for up to 14 days in advance. Find out what's on now or later, change the channel, Icons you may see in the Guide. Press the GUIDE key twice to All Channels, or channels in a specic category.

<https://gabrieliassociati.com/images/Digidesign-Profile-Manual-Pdf.pdf>

Highlight an item by using the arrow Press the RED or GREEN keys to move forward or backward in time. DOWN. Press SELECT to access the. To tune to a program that is on now, highlight the program and press SELECT. Selecting Press INFO when you've highlighted a show in the Guide to view a more indepth Pressing INFO when you've highlighted the channel name Press SELECT when you've highlighted a channel cell far left to view that channel in Press MENU to see Guide options, change your Favorites list, or jump to a desired date Press RECORD to record the program. Info Screen. The Mini Guide. Program Listings While You Watch TV. The Mini Guide is a special version

of the Guide that displays only one channel at a time, To display the Mini Guide, press the BLUE key on the Just as you can with the Guide, you can scroll through channels Mini Guide. Chapter 2 An even better way to catch all your favorites. Recording is a great way to see your favorite programs on your schedule. You won't miss your Just set a program to record and your DIRECTV Plus Receiver To watch recorded programs, use the Playlist feature. See. The Playlist on page 29.. To schedule a program for recording with specific options A screen is displayed where you can set record options for You can record up to two programs at once if you've connected both inputs on your. DIRECTV Plus Receiver. However, if a program you select to record conflicts with another OneTouch Record with Default Options. On any screen, you can press the RECORD key on a highlighted program to schedule it to Pressing RECORD once schedules the highlighted program to record. A recording icon is For episodic programs Autorecord a Find. Programs that match a and see Find by, page 36 can be scheduled to autorecord. When the Once you have scheduled a program to record, you can change the record options or cancel You can change the following record options Recording to VCR. To record a program on your VCR, make sure you've connected your VCR properly to your.

DIRECTV Plus Receiver, then select a recorded program from the Playlist, set your VCR to See your VCR User's Guide for information on how to Chapter 2 The Latest Movies, 24 Hours a Day. You don't have to go out for the best and biggest movies and special events. Recent hits and. View. You'll find them listed in the Guide in the 100s, with previews on channel 100. As long as your receiver has been connected to a landbased phone line, you can use your remote to order. You'll get a reminder You can also order DIRECTV Pay Per. View movies and events on the Internet Keep in mind, though, You can cancel your pay per view order for any reason as long as none of the program has Press LIST, Press SELECT on the Purchase item in the left The Playlist. Watching Your Recorded Programs. The Playlist displays all saved, recorded programs in the Playlist tab. To display the Playlist Other programs, which may include behind the scenes and Check the Showcases tab frequently for exclusive The more programs you have marked. The time, date and channel of each recorded program are displayed to the right of the Highlighting a program title displays the program description, just as in the Guide. Episodic programs appear in the list in groups. For example, if you record a weekly comedy You can press SELECT on the series name to display all the Programs saved as the result of a Find by are also saved The number of new not If you press SELECT or INFO on a program in the Playlist, an Info screen is displayed for Chapter 2 The Playlist displays a Disk Space bar that shows the approximate amount of space available The Disk Space bar shows programs you have designated.

Keep until I Delete in blue, programs subject to expiration in light blue, and the remaining Using the Quick Menu Quick Menu is displayed, use the UP and DOWN arrows to highlight a desired menu item, Some menu items will display a submenu, others To remove the Quick Menu at any time, press MENU The Quick Menu is context sensitive, meaning it shows different options depending upon Settings. Selecting Settings in the Quick Menu displays a submenu of items that lets you customize, Setup. The Setup item in the Quick Menu displays the Setup screen, where you can access the Info. The System Info option lets you view the current system information. The System Test Satellite Access Card Follow the onscreen directions to replace your access card. You will need your old and new Reset. From here you can reset the receiver, reset to factory defaults, or reset everything. Scheduler. This feature gives you an overview of and access to all the programs you've set to record or Favorites. Check the current status of your Favorites lists by clicking here, and make changes if you Parental Controls. Check the current restrictions of your Parental Controls by clicking here, and make any Audio Options. Some programs have alternate audio available such as other language tracks or Dolby. Digital. This option only appears in the Quick Menu over Live TV when the current program has In either case, press MENU while in Live TV, then. To change the default audio, from the Quick Menu, select Settings, select Setup, then select. Audio in the left menu and follow the onscreen instructions. To temporarily change the audio, from the Quick Menu, select Audio

Options, then select Once the program is over or you change the channel, the audio Chapter 3 Programs broadcast using this high quality audio standard are indicated by the words Dolby. Digital in the program description in the Channel Banner see page 23 and the Guide see To change the current Digital Audio format, press MENU, select Settings, then select Setup.

Select Audio in the left menu. Highlight the Dolby Digital tab and press SELECT, then follow Digital Audio if you are using the Digital Audio Out Optical to a digital audio receiver. Audio if you are using the Digital Audio Out Optical to a digital audio receiver and the RF coaxial output cable to your TV or stereo. Category Sort. This feature lets you temporarily arrange the Guide to list only programs in a particular While in the Guide, from the Quick Menu, select Category Sort. To further narrow your To quickly move Press GUIDE to return to the regular Guide, or EXIT to return to live TV. Pay Per View. This option enables you to check out DIRECTV Pay Per View listings by category. While in the Guide, press MENU, then select Pay Per View. You will see three choices for Choose All to display all current pay per view programs. Movies will give Pick Special Events to see specic events such as The Guide will update with matching programs. Chapter 3 Would you like to locate a particular program, movie or sports event you want to see — even Find by offers some easy Press MENU, then select Find by. You can nd a program by Title, Person, Keyword or. Channel. Your search will be quicker if you narrow your search by selecting subcategories; just Once you've found a program you're after, all you have to Recent Finds. If you'd like to repeat a previous search, select Recent Finds, then select your search to view Note. Keep in mind, when you search with Find by, only those programs slated to air within the Guide's number of days of This option gives you a convenient way to look several days ahead in the Guide, without Favorites. Favorites allows you to set up special, customized Guide that shows only those channels you When you're using a Favorites list, the Guide will only display those channels you've Keep in mind, no matter what Favorites list you're currently using, you can still always access You can also edit Channels I Get.

In addition to displaying all channels or creating lists of favorite channels, you can also To see the channels you receive, select Chans I Get from the left menu of the Favorites screen. To set Chans I Get as your current channel list, select the Set Current menu item from the Favorites screen, then change the Current Favorites option to Chans I Get. Chapter 3 Select either Caller. ID or Messages from the left menu, as desired. Caller ID. The Call Log tab displays up to 25 recent incoming calls. Highlight and select a name to The Notication tab lets you turn the notication feature on or off. When the Notication DIRECTV Messages. This feature lets you view a listing of current DIRECTV messages waiting for you. Simply Note Parental Controls enables parents to place certain restrictions on just who's watching what, Whether it's for mature content or Press MENU to display the Quick Menu, SELECT Parental Controls, then Edit Settings, and The system default is "unlocked" for all Ratings. Here you can set rating limits for Movies and TV. Select Ratings. Move to the right to SELECT another tab. Note You can use RED or. GREEN to cycle tabs. SELECT toggles the item on and Movies. Highlight and select the Movies tab, then set the overall rating limit you wish to impose Brief TV Programs. Select the TV tab, then highlight and select the TV rating you desire. You can also set ratings Other Shows. To block programming that has no rating — such as news and sports and shows with a rating Chapter 3 You can block viewing of a certain channel or channels from this menu. SELECT Chan Blocks in the left menu, then scroll down the channel list to SELECT those Use Block All or Allow All Spending. From the left menu, SELECT Spending, then set your preferred spending limit Simply key in the amount using the numbers on your Hours. From the left menu, SELECT Hours, then set your preferred hours during which TV can Now, lock it. Once you've set the restrictions you want, choose Lock Now from the left menu.

You'll be An onscreen message will appear whenever anyone tries to tune to a channel or program that He or she will not Using your passcode, you can easily override the Temporarily or permanently unlocking a restriction is easy. To temporarily unlock a For more unlock options Channel Banner will

tell you if the Locked. Unlocked. Temporarily. Unlocked SELECT one and enter your password. Also note If you have Parental Controls set and temporarily unlocked, turning the receiver If anyone tries to unlock restrictions using an invalid passcode, To change your passcode at any time Chapter 3 The Quick Menu includes special recording features over certain screens. Quick Menu over the Playlist screen. Quick Menu over recorded TV Quick Menu over a Record Options screen Troubleshooting Receiver. If you experience image freezes, audio freezes or blank screen, or the system won't Press the red RESET button behind the access card panel door on the front of the DIRECTV Plus Receiver, then wait for program guide info to be acquired. System Upgrades. Your DIRECTV Plus Receiver is able to receive upgrades or modifications to some of its These modifications will occur automatically, usually at times If your receiver is on when an upgrade or Do not unplug your receiver while an upgrade is in progress. Please consult the System Info Note. If preferred, you can have an Authorized Service Representative visit your home for a fee, to set up your digital satellite For details about this service, call 1800 DIRECTV or visit DIRECTV.com. DIRECTV Plus Receiver or TV Problems. The DIRECTV Plus Receiver and most TVs, VCRs and DVDs let you toggle between video sources. If you don't see the signal you think Problems with Caller ID. Also, check to be sure your Caller ID notification is turned on see page 38. See the user's manual that came with the wireless phone jack to see if it doesn't, either connect the phone line directly to a standard wallmount phone jack or install a DIRECTV Plus Receiver will not turn on Wait ve minutes.

Plug it in again. Chapter 4 Wait 30 seconds, then turn on again. If this happens frequently, the voltage in your house may be DIRECTV Plus Receiver turns on or changes channels unexpectedly. See page 26. Blank screen. Your DIRECTV Plus Receiver may be hooked up incorrectly to the TV. Press the INFO key on the front panel of the DIRECTV Plus Receiver to see if the channel banner appears. If it does not, check the Setup and Connections section for instructions about connecting Press the TV INPUT key on the remote to make sure your TV input is set to the TV input your DIRECTV Plus Receiver is connected Press the POWER key on the front of the DIRECTV Plus Receiver. Press the red RESET button behind the door on the front panel of the DIRECTV Plus Receiver. Temporary loss of the satellite signal or Searching for Satellite Signal message. Your satellite system may be experiencing rain fade, a temporary loss of the satellite signal due to unusually heavy rain clouds or Your dish may be blocked. Check that something is not blocking the dish. In the left menu, select Satellite, then Repeat Satellite Dish. Setup button. Follow the steps. From the Satellite Dish Type screen, make sure the proper dish type is selected round, oval with a dual LNB or oval with a triple LNB. Enter a channel number manually, or press MENU on the A program I tried to record does not show up in the Playlist. In the left menu, select History. You will see a list of recent programs, with their recording I wanted to record a program, but I got an error message saying it conflicted with another scheduled record. What do I do You will have to decide which program you want to cancel. I recorded a program, and the recording got cut off just before the end, so I missed the last bit of the program. Some networks show Note that adding time to the beginning or end of a recording increases the likelihood of recording Chapter 4 Needed.

When you schedule a program with onetouch record, the recording defaults to Until Space Needed. Programs that are set to You can change this option for a completed recording by When the program's Info screen is displayed, select I've set up an episodic recording, but now I get a bunch of reruns and multiple copies of the same program. If you only want to This is the default for Access the program's Info screen by pressing the INFO key when the program is highlighted in any list or the Guide, then select the. Record menu item and change the options as needed. My video and audio are out of sync. Press MENU, press SELECT on Settings, then SELECT Setup. Select the. Reset item from the left menu and follow the onscreen instructions. My DIRECTV Plus Receiver is "frozen" on a single frame of a TV picture. You must buy the Press the PLAY key. Reset item from the left menu and follow the onscreen instructions. When I am watching a recorded program, and the DIRECTV Plus Receiver starts to record another program, my image quality SELECT the program you were

watching from the Playlist and press PLAY. You may want to watch a program, but all I get is a black screen. When I go to the Guide or another screen, the TV window is black. Cancel one of the recordings, or wait until a recording is complete. I want to turn the light ring on the front panel on or off, or dim them. To turn the lights on, press and hold the LEFT and RIGHT arrows again. Chapter 4 Problems with the remote control. Make sure the remote control is in DIRECTV mode. Slide the MODE switch to the DIRECTV position so the remote will control the. Check the batteries in the remote control. They may be weak, dead or installed incorrectly. Try replacing batteries. If you're entering a channel number that is less than four digits long, the receiver might wait two seconds before tuning to the channel. Press ENTER after entering a channel number to tune immediately.

If you are trying to operate a device other than the DIRECTV Plus Receiver that you have programmed the remote to control, make sure the input switch is clicked into a remote control indicator light starts flashing. The batteries in the remote control are running low and should be replaced soon. Note that when you replace the batteries, you may have to FineTuning the Signal. If you self-installed your satellite dish antenna, you may have already used Guided Setup to find the dish pointing coordinates, acquire and If you need to run Guided Setup again, select Settings from the Quick Menu, then select Guided. Setup. Next, press SELECT on Satellite, then select Repeat Satellite Setup. Note DIRECTV Plus Receiver. Running the System Test. The System Test allows you to run a basic diagnostics check on your DIRECTV Plus Receiver. If you are experiencing any trouble It will also allow you to get your access card and receiver ID numbers or to initiate diagnostic First make sure that. All connections — jacks, cables, etc. — are in place correctly see Chapter Two. Getting Connected, for more info. Follow these steps to run the diagnostics system test on your DIRECTV Plus Receiver. You should run a system test several times before concluding that there is a problem. Occasional outcations in the phone line or satellite Chapter 4 DIRECTV warrants your DIRECTV Plus Receiver Model Number R15 and any included accessories against defects in material or workmanship for a period Who is Covered You must have proof of purchase to receive warranty service. A sales receipt or other document showing that you purchased the product is considered proof Warranty coverage begins the day you purchase the product. For ninety 90 days from the purchase date, at the option of DIRECTV, the DIRECTV Plus.

<http://www.bouwdata.net/evenement/boss-cs-3-owners-manual>